

SETIING UP MAGICAD

CONTENT

Installing MagiCAD	1
Activating MAGICAD	6


INSTALLING MAGICAD

1. Through you web browser (Chrome, Internet Explorer eller andet) go to website:
<https://portal.magicad.com/Download/GetProductCategoryList?categoryId=1>

Remember to select Autodesk Revit under Technology (default is set to Autodesk AutoCAD).

Download MagiCAD

Welcome to the MagiCAD download page. To download MagiCAD installation package, define Autodesk technology and operating system, select the MagiCAD version, download site, MagiCAD product and sign in to begin download.




The screenshot shows the MagiCAD download interface with the following configuration:

- TECHNOLOGY:** Autodesk Revit
- OPERATING SYSTEM:** Windows 64-bit
- MAGICAD VERSION:** 2021
- MAGICAD PRODUCT:** MagiCAD 2021 for Revit 2021 (EXE)
- DOWNLOAD LOCATION:** Europe

Below the configuration, it displays the date "03.06.2020" and the file size "1,1 GB". A button labeled "Sign in to download" is highlighted with a blue arrow. At the bottom, under "OTHER USEFUL TOOLS", there are links for "MagiCAD templates", "Network License Server Utilities", and "Installation instructions".

Click Sign in to download.

2. Insert MagiCad activation ID:
Act-60b6c1b8-6c47-49e6-a3b4-cc2317ec57ec-0
 and click Sign in.



Sign in

Please sign in using your MagiCAD activation ID. You can find it from the email we sent you upon the purchase.

MagiCAD activation ID


Close SIGN IN

3. After login you will get this screen.
Remember to select Autodesk Revit under Technology (default is set to Autodesk AutoCAD).

Click Download.

Download MagiCAD

Welcome to the MagiCAD download page. To download MagiCAD installation package, define Autodesk technology and operating system, select the MagiCAD version, download site, MagiCAD product and sign in to begin download.



TECHNOLOGY  Autodesk Revit

OPERATING SYSTEM  Windows 64-bit

MAGICAD VERSION  2021

MAGICAD PRODUCT  MagiCAD 2021 for Revit 2021 (EXE)


DOWNLOAD LOCATION  Europe

03.06.2020 1,1 GB **DOWNLOAD** [Reset code](#)


OTHER USEFUL TOOLS [MagiCAD templates](#)
[Network License Server Utilities](#)
[Installation instructions](#)

4. Download the zip-file, unpack the file and install (double-click **MagiCAD 2021 for Revit 2021.exe**, from where you unpacked the file. The way to unpack files varies depending on which program you use to unpack zip-files.


5. Tick both options.




6. Tick Accept the terms... and click Next




7. Choose program language and click Next.




8. Click Next



9. Click Install




10. Click Finish




ACTIVATING MAGICAD


11. After installation, the Magicad folder will appear in the Start Menu.
Open License Management Utility



12. Select Options




13. Type 2800@magicad.ait.dtu.dk i Server and 2194 i License borrow port
Click Test connections.



The image shows a 'Network settings' dialog box. It has two main sections: 'Stand Alone License Activation' and 'Network License Usage'. In the 'Stand Alone License Activation' section, the 'Use MagiCAD Activation Server (recommended)' radio button is selected. In the 'Network License Usage' section, the 'Use network licenses' checkbox is checked. Below this, there are two text input fields: 'Server' containing '2800@magicad.ait.dtu.dk' and 'License borrow port' containing '2194'. At the bottom left of the dialog is a 'Test connections' button, which is highlighted by a blue arrow. At the bottom right are 'Save' and 'Cancel' buttons.

14. Connection OK are to appear 4 times. Click Close.




The image shows a 'Connection test' dialog box. It has a title bar with a red icon and the text 'Connection test'. Below the title bar is a section titled 'Testing network settings...' with a green progress bar. Below the progress bar is a table with four rows, each showing a service name and its connection status. All four services show 'Connection OK.'. At the bottom right of the dialog is a 'Close' button.

MagiCAD Activation Server	Connection OK.
MagiCAD License Data Service	Connection OK.
Local Network License Server	Connection OK.
Local License Information Service	Connection OK.

15. Click Save

16. Click the tab Networks Licenses

Choose the lowest Subscription (borrowable). See below for example of borrowing MagiCad license.



17. Click Borrow

Choose a date 30 days in the future.

License is now shown with a return date as on the picture below.

Click Exit

